



- Ensure cams (B) are inserted into the shelf with arrow pointing to the edge
- Screw Cam Pins (A) into sides carefully
- Carefully align shelf and sides.
- When in place, turn cam a half turn clockwise to lock in position
- Screw Hook D to back of side using screws C into the pre drilled holes.
- Please apply the 8 self-adhesive Door Buffers to the underside face of the hooks, to prevent accidentally scratching the side rail.